


1




MultiLight Splitter

2



Pull the nylon cord through the top of the "housing" and the centre of the locking screw

3



Thread the cord in a loop around the locking screw, making sure the cord is well placed in the grooves

4



Insert locking screw into the "housing", and tighten slightly with a screwdriver

5



Before tightening the screw completely, slide the "housing" towards the luminaire chassis, and make sure it's plane

6



Completely fasten the locking screw to the "housing"

7



Cut the cord as close to the “housing” as possible

8



Attach and tighten the strain relief

Recommended cable length between the User Panel and the luminaire is 20 cm

